


# datavideo



4K IP VIDEO DECODER

**NVD-40**

**Instruction Manual**

[www.datavideo.com](http://www.datavideo.com)

# Contents

<b>FCC COMPLIANCE STATEMENT .....</b>	<b>4</b>
<b>WARNINGS AND PRECAUTIONS .....</b>	<b>4</b>
<b>WARRANTY.....</b>	<b>5</b>
STANDARD WARRANTY .....	5
THREE YEAR WARRANTY.....	6
<b>DISPOSAL.....</b>	<b>6</b>
<b>PRODUCT OVERVIEW.....</b>	<b>7</b>
FEATURES .....	7
<b>FRONT PANEL .....</b>	<b>8</b>
<b>REAR PANEL.....</b>	<b>9</b>
<b>HOW TO FIND THE NVD-40 ON AN IP NETWORK .....</b>	<b>11</b>
HOW TO USE THE NVD-40 IP FINDER UTILITY SOFTWARE .....	11
<b>NVD-40 LOGIN USING A WEB BROWSER.....</b>	<b>12</b>
DEFAULT LOGIN DETAILS .....	12
<b>NVD-40 WEB BROWSER HOME PAGE .....</b>	<b>13</b>
SETTINGS OPTION.....	13
<b>SETTINGS &gt; AUDIO SETUP .....</b>	<b>13</b>
<b>SETTINGS &gt; DISPLAY SETUP.....</b>	<b>14</b>
<b>SETTINGS &gt; NETWORK SETUP .....</b>	<b>15</b>
<b>SETTINGS &gt; LIVE STREAM SETUP.....</b>	<b>17</b>
DECODING VIDEO FROM THE NVS-33/34/35/40 ENCODERS.....	19
DECODING A RTMP PUSH STREAM .....	19
DECODING OTHER STREAM TYPES.....	20
DECODING FROM A VIDEO SHARING WEBSITE .....	20
<b>SETTINGS &gt; ACCOUNT SETUP.....</b>	<b>21</b>
<b>SETTINGS &gt; STB MODE.....</b>	<b>22</b>

RMC-12 IR REMOTE.....	23
<b>SETTINGS &gt; CEC CONTROL.....</b>	<b>24</b>
<b>SETTINGS &gt; PLUGINS.....</b>	<b>25</b>
<b>SETTINGS &gt; CLOUD .....</b>	<b>25</b>
CONNECT THE NVD-40 TO DV CLOUD.....	25
CONTROL VIA DV CLOUD .....	26
LINK TO A LIVE CHANNEL ON DV CLOUD.....	27
<b>AUTOMATIC FIRMWARE UPDATES .....</b>	<b>30</b>
<b>DATAVIDEO NVD-40 SOCKET COMMANDS .....</b>	<b>31</b>
<b>PORT FORWARDING ON YOUR FIREWALL / ROUTER.....</b>	<b>32</b>
<b>DIMENSIONS .....</b>	<b>33</b>
<b>SPECIFICATIONS .....</b>	<b>34</b>
<b>SERVICE &amp; SUPPORT .....</b>	<b>36</b>

**Disclaimer of Product & Services**

The information offered in this instruction manual is intended as a guide only. At all times, Datavideo Technologies will try to give correct, complete and suitable information. However, Datavideo Technologies cannot exclude that some information in this manual, from time to time, may not be correct or may be incomplete. This manual may contain typing errors, omissions or incorrect information. Datavideo Technologies always recommend that you double check the information in this document for accuracy before making any purchase decision or using the product. Datavideo Technologies is not responsible for any omissions or errors, or for any subsequent loss or damage caused by using the information contained within this manual. Further advice on the content of this manual or on the product can be obtained by contacting your local Datavideo Office or dealer.

## FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## Warnings and Precautions

1. Read all of these warnings and save them for later reference.
2. Follow all warnings and instructions marked on this unit.
3. Unplug this unit from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this unit in or near water.
5. Do not place this unit on an unstable cart, stand, or table. The unit may fall, causing serious damage.
6. Slots and openings on the cabinet top, back, and bottom are provided for ventilation. To ensure safe and reliable operation of this unit, and to protect it from overheating, do not block or cover these openings. Do not place this unit on a bed, sofa, rug, or similar surface, as the ventilation openings on the bottom of the cabinet will be blocked. This unit should never be placed near or over a heat register or radiator. This unit should not be placed in a built-in installation unless proper ventilation is provided.
7. This product should only be operated from the type of power source indicated on the marking label of the AC adapter. If you are not sure of the type of power available, consult your Datavideo dealer or your local power company.
8. Do not allow anything to rest on the power cord. Do not locate this unit where the power cord will be walked on, rolled over, or otherwise stressed.
9. If an extension cord must be used with this unit, make sure that the total of the ampere ratings on the products plugged into the extension cord do not exceed the extension cord's rating.
10. Make sure that the total amperes of all the units that are plugged into a single wall outlet do not exceed 15 amperes.
11. Never push objects of any kind into this unit through the cabinet ventilation slots, as they may touch dangerous voltage points or short out parts that could result in risk of fire or electric shock. Never spill liquid of any kind onto or into this unit.
12. Except as specifically explained elsewhere in this manual, do not attempt to service this product yourself. Opening or removing covers may expose you to dangerous voltage points or other risks, and will void your warranty. Refer all service issues to qualified service personnel.
13. Unplug this product from the wall outlet and refer to qualified service personnel under the following conditions:

- a. When the power cord is damaged or frayed;
- b. When liquid has spilled into the unit;
- c. When the product has been exposed to rain or water;
- d. When the product does not operate normally under normal operating conditions. Adjust only those controls that are covered by the operating instructions in this manual; improper adjustment of other controls may result in damage to the unit and may often require extensive work by a qualified technician to restore the unit to normal operation;
- e. When the product has been dropped or the cabinet has been damaged;
- f. When the product exhibits a distinct change in performance, indicating a need for service.

## Warranty

### Standard Warranty


- Datavideo equipment are guaranteed against any manufacturing defects for one year from the date of purchase.
- The original purchase invoice or other documentary evidence should be supplied at the time of any request for repair under warranty.
- The product warranty period begins on the purchase date. If the purchase date is unknown, the product warranty period begins on the thirtieth day after shipment from a Datavideo office.
- All non-Datavideo manufactured products (product without Datavideo logo) have only one year warranty from the date of purchase.
- Damage caused by accident, misuse, unauthorized repairs, sand, grit or water is not covered under warranty.
- Viruses and malware infections on the computer systems are not covered under warranty.
- Any errors that are caused by unauthorized third-party software installations, which are not required by our computer systems, are not covered under warranty.
- All mail or transportation costs including insurance are at the expense of the owner.
- All other claims of any nature are not covered.
- All accessories including headphones, cables, and batteries are not covered under warranty.
- Warranty only valid in the country or region of purchase.
- Your statutory rights are not affected.

### Three Year Warranty

- All Datavideo products purchased after July 1st, 2017 are qualified for a free two years extension to the standard warranty, providing the product is registered with Datavideo within 30 days of purchase.
- Certain parts with limited lifetime expectancy such as LCD panels, DVD drives, Hard Drive, Solid State Drive, SD Card, USB Thumb Drive, Lighting, Camera module, PCIe Card are covered for 1 year.
- The three-year warranty must be registered on Datavideo's official website or with your local Datavideo office or one of its authorized distributors within 30 days of purchase.



### Disposal



#### For EU Customers only - WEEE Marking

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects

human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



**CE Marking** is the symbol as shown on the left of this page. The letters "CE" are the abbreviation of French phrase "Conformité Européene" which literally means "European Conformity". The term initially used was "EC Mark" and it was officially replaced by "CE Marking" in the Directive 93/68/EEC in 1993. "CE Marking" is now

used in all EU official documents.

## Product Overview

The Datavideo NVD-40 is a wired IP video decoder with HDMI, Composite and analogue audio outputs.

The NVD-40 decodes all common protocols including SRT, RTSP, RTMP, UDP, TCP, HTTP, HLS and MPEG-TS and can output SD/HD video at resolutions up to 1080p60.

Decodes directly from YouTube Live, UStream and most major CDNs without any 3rd party advertising.

The NVD-40 is the perfect partner to the Datavideo NVS-33/34/35/40 IP encoders allowing full HD point to point video links over Ethernet, WiFi or the Internet.


When connected to dv Cloud (<https://www.dvcloud.tv/>) the NVD-40 is controllable from anywhere in the world and can be easily connected to any encoder via the cloud.

When connected to a Datavideo DVS-200 server or dv Cloud, the NVD-40 can function as an IPTV set top box downloading a channel list of both live and pre-recorded streams automatically.

### Features

- Operates on standard 10/100Mb Ethernet networks
- Excellent image quality with very low delay
- Unicast and multicast support
- Supports RTSP (Unicast/Multicast), RTMP, UDP (Unicast/Multicast), TCP, HTTP, HLS and MPEG-TS
- Supports SRT listener mode
- Built in RTMP server for point to multipoint distribution
- Direct decoding from most major CDNs without any 3rd party advertising
- Remote control via dv Cloud
- Channel list download from DVS-200 Cloud Streaming Server
- Feature-rich WebUI for configuration and control
- Built in video scaler
- Supports Full HD video and audio
- Supports simultaneous digital embedded and analogue audio output
- Supports remote control by socket commands
- Small form factor, rack mountable using RMK-1
- Supports HDMI and Composite video output
- Supports CEC control

## Front Panel



### Power On/Off Switch

Switches the power On / Off

**Power LED:** The red power LED indicates that the NVD-40 has an active power supply.




### LAN Status LED

**ACT LED:** The flashing yellow ACT LED indicates LAN activity (data upload and download).

**LINK LED:** The green LINK LED indicates active LAN link.




## Rear Panel



### AUDIO OUT (RCA)

RCA stereo for a line level analogue audio.



### HDMI OUT

HDMI digital signal output connector

### CVBS OUT (BNC)

Composite video output

### LAN



### Ethernet Port (RJ-45)

10/100M base Ethernet Network interface

### DC IN 12V



### DC In Socket

Connect the supplied 12V PSU to this socket. The connection can be secured by screwing the outer fastening ring of the DC In plug to the socket.

**RESET**



**Reset Button**

Press and hold for at least 5 seconds to reset the device to its factory default settings (including the password).

**USB**



**USB**

Functions currently under development.


## How to find the NVD-40 on an IP network

By default, once the physical connections have been established, the **NVD-40 will try to obtain an IP Address from a DHCP network server**. As we will see this can be changed later to a Static IP address if required.

### How to use the NVD-40 IP Finder Utility Software

Datavideo supplies a free, *Windows based* utility, called **NVD & NVP IP Finder**. The utility is also available for download on the product page of the official website.

The first time this software is used on the computer you may need to allow it permission through your computer's firewall / anti-virus software in order for it to be able to scan or search the local network.



When the utility scans the LAN that the computer is connected to, it displays the current IP address for any NVD-40 units found on this local IP network. Double clicking on the device listed will automatically open your computer's default web browser and navigate to the login page of the NVD-40.

If you are using an Apple computer then you can use an alternative utility app such as Fing or Network Analyzer Lite.

## NVD-40 Login using a Web Browser

Type the numbers of the IP address for the NVD-40 into the search bar of the browser. Remember to include the dots in between the numbers. When entered you will then be asked to login to the NVD-40.

Alternatively you can simply double click the IP address listed in the NVD-40 IP finder.



The image shows a web browser login interface for the NVD-40. It features a blue header bar with the text "Enter Your Login Credentials". Below this, there are two input fields: "Login User" with a placeholder "Username" and "User Password" with a placeholder "Password". A blue "Login" button is positioned below the password field.


### Default Login Details

All NVD-40 units are delivered from the factory with the same default user name and password. This can be changed at a later stage to suit your needs.

**User** = admin      **Password** = 000000 [Zero six times]

**Please Note:** We recommend Google Chrome or Mozilla Firefox web browsers.

## NVD-40 Web Browser Home Page




Once we have logged into the NVD-40 we are presented with the **Home page**.

### Settings option

When clicked, the Settings option tab will open a new page. There are five sections of settings which can be looked at. These are: **Audio Setup**, **Display Setup**, **Network Setup**, **Live Stream Set Up**, **Cloud** and **Account Setup**, **STB Mode**, **CEC Control** and **Plugins**.

## Settings > Audio Setup


By default, the NVD-40 will output audio over the digital HDMI connection. Alternatively, you can choose to output via the analogue audio via the RCA connections.



## Settings > Display Setup

By default the NVD-40 will output video over the digital HDMI port at a resolution of 2160P 50 fps and RGB colourspace.

**Please note:** The set resolution is only applied when the stream is decoding, the device will output your monitor's preferred resolution as it boots.



The screenshot shows the 'datavideo' web interface. The top navigation bar includes 'Home', 'Settings' (which is highlighted), 'Stats', and 'Logout (admin)'. On the left side, there is a vertical menu with buttons for 'AUD Audio Setup', 'VID Display Setup' (which is selected), 'NET Network Setup', 'LIVE Live Stream Setup', 'CLD Cloud', 'A/C Account Setup', and 'STB STB Mode'. The main content area is titled 'Display Configuration' and contains a warning: 'Warning , not all resolutions will work on your display'. Below this is the 'Choose Output' section with a dropdown menu set to 'HDMI (Digital)' and a 'Rotate / Flip' dropdown set to 'Off'. The 'HDMI' section includes a 'Screen' dropdown set to '2160p 50 (64:27)', a 'Resolution' dropdown, an 'HDMI' dropdown set to 'RGB', and a 'Colorspace' dropdown. A 'Save Changes' button is located at the bottom right of the configuration area.

### Output To

Here you can select to output video digitally over HDMI or over the SD analogue composite connection.

### HDMI (Digital)

When digital is selected you can select a screen resolution from SD PAL/NTSC right up to DCI 4K60. The NVD-40 will scale your source video to match the output resolution however the aspect ratio (4:3 or 16:9) should be matched to avoid black space on the output, for optimal performance match the output resolution to the source video. The colour space can be switched between YUV (YCbCr) and RGB, most video equipment will use the YUV colour space however if the colors appear wrong on your display please try RGB.

### Composite (Analogue)

When analogue is selected the UI will change and you can only select between PAL and NTSC resolution with a 4:3 or 16:9 aspect ratio.

The screenshot shows the 'datavideo' web interface. The top navigation bar includes 'Home', 'Settings' (highlighted), 'Stats', and 'Logout (admin)'. On the left, a sidebar lists menu items: AUD Audio Setup, VID Display Setup, NET Network Setup, LIVE Live Stream Setup, CLD Cloud, and A/C Account Setup. The main content area is titled 'Display Configuration' and includes a warning: 'Warning , not all resolutions will work on your display'. Below this is the 'Choose Output' section with 'Output To' set to 'Composite (Analog)' and 'Rotate / Flip' set to 'Off'. The 'Composite' section has 'Composite Mode' set to 'PAL' and 'Aspect Ratio' set to '4:3'. A 'Save Changes' button is at the bottom.

### Rotate / Flip

Provides the option to rotate or flip (mirror) the video output, default is off.

## Settings > Network Setup

The screenshot shows the 'datavideo' web interface for 'Network Setup'. The top navigation bar includes 'Home', 'Settings' (highlighted), 'Stats', and 'Logout (admin)'. The left sidebar lists menu items: AUD Audio Setup, VID Display Setup, NET Network Setup, LIVE Live Stream Setup, CLD Cloud, A/C Account Setup, STB STB Mode, CEC CEC Control, and PLU Plugins. The main content area is titled 'Network Configuration. Mandatory Fields marked \*'. Under 'IPv4 Configuration', 'Network Type' is set to 'Automatic Configuration(DHCP)'. The 'Proxy' section has 'HTTP(S) Proxy' set to 'http://your.ip.port/'. The 'Time' section has 'NTP' set to 'Leave blank for defaults'. The 'Security' section has 'Enable Telnet Commands' unchecked. A 'Save Changes' button is at the bottom.

By default the NVD-40 will obtain its IP address automatically from a DHCP server.

If you intend to connect the NVD-40 directly to a PC or network without a DHCP server then you should assign a manually set IP address by selecting 'Static Configuration'.

We recommend that only advanced users who are aware of IP addressing set the manual 'Static Configuration' IP address. Your local network administrator or I.T. support may be able to help you with this.

### Proxy

Here you can set the NVD-40 to connect to the internet via a proxy server. Proxy server is also a way to bypass a firewall if there is one. Simply enter the proxy IP and the port number as depicted below.

## Proxy

---

HTTP(S) Proxy

### Time

By default, the NVD-40 will synchronize its internal clock with public NTP servers, if your network does not allow connections to external servers you can specify your internal NTP servers here. It is important the internal clock is correct for secure HTTPS:// stream sources to work.

## Time

---

NTP

Servers(comma  
separated)

### Security

Here you can enable the internal telnet server, this is used so that the NVD-40 can be controlled by third party applications using socket commands. Please see the socket commands section of this manual for more information.



## Settings > Live Stream Setup

From this page you can configure the source stream for the decoder. The NVD-40 supports the following stream types:

- RTSP over UDP (Unicast / Multicast)
- RTSP over TCP
- RTSP over HTTP
- SRT (Secure Reliable Transport) caller
- MPEG-TS over UDP
- RTMP Pull
- RTMP Push (Internal Server)
- UDP raw (Unicast/Multicast)
- HLS over HTTP
- MPEG-TS over TCP Pull

The screenshot shows the 'Live Stream Setup' page in the DataVideo interface. On the left is a sidebar with navigation buttons: AUD (Audio Setup), VID (Display Setup), NET (Network Setup), LIVE (Live Stream Setup), CLD (Cloud), and A/C (Account Setup). The main content area is titled 'Stream Configuration' and includes the text: 'SRT, RTSP, RTP, UDP, RTMP and TCP streams are supported'. Below this is a section 'Choose Input Stream' with the following fields: 'Decoder Mode' (a dropdown menu set to 'Default'), 'Input Stream' (a text input field containing 'srt://192.168.0.3:1200'), 'Buffer Size' (a dropdown menu set to '0.30 s'), 'SRT Latency' (a text input field set to '120'), 'SRT' (an empty text input field), and 'Passphrase' (an empty text input field). A 'Save Changes' button is located at the bottom right of the configuration area.

### Decoder Mode

**Default mode** should be used for decoding standard streams from encoders such as SRT, RTSP, RTMP, HTTP etc.

Selecting the **RTMP Server (Internal)** mode automatically generates an RTMP URL and a stream key which should be entered into the corresponding fields on Datavideo NVS devices or any other video streaming encoders.

The RTMP playback URL can be used to distribute the stream to multiple other decoders, the number of concurrent RTMP clients is limited only by the 100Mbps ethernet port.

**Video Sharing & HLS** mode should be used for decoding from supported video sharing websites, such as:

- Dailymotion
- Livestream
- Twitch
- UStream
- YouTube Live

Please check the product page on the [datavideo.info](http://datavideo.info) website for a full list of supported video sharing websites.

This mode also supports HLS streams, unlike **Default** mode you can select the resolution of the stream you wish to decode if the HLS stream contains multiple variants.

### **Input Stream**

Enter the URL for the source stream here

Example for **Default** mode:

```
rtsp://192.168.1.50/stream1  
rtmp://192.168.1.50/live/stream1  
srt://192.168.1.50:9000
```

Example for **Video Sharing & HLS** mode:

<https://www.youtube.com/watch?v=y60wDzZt8yg>

Example for RTMP server mode:

```
rtmp://192.168.2.16:1935/stream/stream
```

### **Buffer Size**

This determines how much video is buffered before playback starts, the default 0.3 seconds should be suitable for streaming over Ethernet but a larger buffer may be required in environments with poor network stability to achieve smooth video when streaming over the internet or WiFi. If you notice the video stuttering or the audio breaking up you should increase the buffer size.

**Note: You might experience long delay if the buffer size is too big.**

### **RTSP protocol**

Only displayed if an RTSP stream is being used, the transport protocol can be manually specified.

### **SRT Latency**

Only displayed if an SRT stream is being used. Secure Reliable Transport (SRT) achieves high-quality, low latency streaming across unreliable Internet connections via UDP packets. If packets are lost in transit to the NVD-40, a

request to retransmit the lost packets is sent back to encoder. You can adjust the latency to improve the Quality of Service (QoS) of the stream and reduce the number of dropped packets. You can add from 20 ms to 8000 ms of latency to the SRT stream. Increasing latency gives more time to buffer packets and resend any that got lost in transit to the destination. If the latency value set for the stream is too low and there is packet loss over the network, retransmission of lost packets will not be possible, and the stream quality will suffer.

### **SRT Passphrase**

If the SRT stream is encrypted, you must enter the passphrase here to decode the stream.

### **Decoding video from the NVS-33/34/35/40 encoders**

To decode video from the NVS the NVD-40 must be on the same local network (Ethernet/WiFi) or be able to access the NVS stream over the internet.

### **When the NVS is in RTSP TCP/UDP mode**

Simply copy the RTSP URL from the 'Live' tab of the NVS and enter it into the 'Input Stream' field on the NVD-40. When streaming over LAN it is recommended to set the NVS in RTSP (TCP/UDP) mode.

### **When the NVS is in RTMP mode Local server mode**

Simply copy the RTMP URL from the 'Live' tab of the NVS and enter it into the 'Input Stream' field on the NVD-40

### **When the NVS-33/34/35/40 are in HLS mode**

Simply copy the HLS URL from the 'Live' tab of the NVS and enter it into the 'Input Stream' field on the NVD-40

**Please Note:** When in HLS mode, the buffer size should be set to 1.0 seconds or higher, if you notice audio artifacts you should increase the buffer size.

### **Decoding a RTMP push stream**

To decode a RTMP push stream, first set the decoder mode to RTMP Server (Internal) which should automatically generate an RTMP URL and a stream key. Simply enter the RTMP URL and stream key into the corresponding fields on Datavideo NVS devices or any other video streaming encoders.

**datavideo** Home Settings Stats Logout (admin)

**AUD** Audio Setup

**VID** Display Setup

**NET** Network Setup

**LIVE** Live Stream Setup

**CLD** Cloud

**A/C** Account Setup

Stream Configuration.  
You can stream directly to this decoder using the RTMP URL and stream key below

RTMP URL: rtmp://192.168.10.10:1935/stream

Key: stream

Playback URL: rtmp://192.168.10.10:1935/stream/stream

**Choose Input Stream**

Decoder Mode: RTMP Server(Internal)

Input Stream: rtmp://192.168.10.10:1935/stream/stream

Buffer Size: 0.30 s

RTMP Key: stream

Save Changes

## Decoding other stream types

To decode other stream types such as UDP multicast or TCP, simply enter the stream URL into the 'Input Stream' field of the NVD-40.

### Listening for a Pushed UDP Stream

To listen for a pushed UDP stream, enter the following URL into the 'Input Stream' field of the NVD-40.

udp://@:9710

Replace 9710 with the port number of the pushed stream.

### Decoding from a video sharing website

First you must set the decoder mode to 'Video Sharing', then simply copy the URL from your web browser into the 'Stream URL' field on the NVD-40.

For example:

<https://www.youtube.com/watch?v=y60wDzZt8yg>

Optionally you can select the preferred stream resolution.

**Preferred**

HD (1080p or lower) v


**Stream**

## Settings > Account Setup

The NVD-40 has one admin user account and password. This account is used to keep the NVD-40 secure and gives access to the streaming settings.

Default user name = **admin**      Default password = **000000** [Zero six times]

This section describes how to change the default username and password shown above to something new which is more secure.



1. Log in with the NVD-40 server as normal using the computer web browser.
2. Click **Setting**
3. Click **Account Setup**
4. Click admin and then enter the new **user name and password**.
5. Click 'Change Pass'

**Please Note:** Please be careful and memorize the new login details as the old or default login is deleted during this process.

## Settings > STB Mode

The STB mode can only be used along with a Datavideo DVS-200 stream server or dv Cloud please visit <https://www.datavideo.com/> for more information on the DVS-200 and <https://www.dvcloud.tv/> for more information on dv Cloud.

When enabled, the NVD-40 will connect to the DVS-200 or dv Cloud server and download a list of available live and VOD channels, these channels will be displayed on the HDMI output. Channels can be selected using the supplied IR remote control.

When used with DVS-200 only HLS streams will be decoded so low latency is not possible in this mode, when used with dv Cloud SRT streams will also be available if low latency is required.

datavideo

Home Settings Stats Logout (admin)

**AUD** Audio Setup

**VID** Display Setup

**NET** Network Setup

**LIVE** Live Stream Setup

**CLD** Cloud

**A/C** Account Setup

**STB** STB Mode

STB Configuration.

dv Cloud / DVS-200 STB Mode

STB Mode

Hostname

Port

Username

Password

Remove background image

Upload background image  No file chosen (16:9)

### STB Mode

When enabled, the 'Live stream setup' options will be disabled, the NVD-40 will display a channel list on the HDMI output and control is only using the [supplied IR remote](#).

**Please Note:** STB Mode is intended for use with HDMI output only.

**Hostname:** Enter the DVS-200 machines IP

**Username:** Enter the DVS-200 user accounts you wish to download channels from, you will only see channels this user account has access to.

**Password:** Enter the DVS-200 user accounts password

### Upload background image

Here you can upload a custom background image, this image is displayed behind the on screen channel list.

### Remove background image

Removes the uploaded background image and restores the default.

Once connected you will see the on screen channel list on the HDMI output.



### RMC-12 IR Remote



The NVD-40 is supplied with the RMC-12 IR control. Its key definitions are as follows:

**Vol +** - Increases volume (only active when playing back)

**Vol -** - Decreases volume (only active when playing back)

**CH List** – Stops playback and loads the channel list

**Play/Pause** – Pause and resumes playback (only active when playing back)

**Note: In STB mode, you can only pause for as long as the HLS playlist length on DVS-200.**

**OK** – Plays the selected channel

**Up** – Used for channel list navigation

**Down** – Used for channel list navigation

**Left** – Used for channel list navigation and seeking during playback

**Right** - Used for channel list navigation and seeking during playback

**Return** – Used to close the channel list and resume playback of the last seen channel

**Power** – Turn NVD-40 into standby mode

## Settings > CEC Control

This menu option allows remote users to turn the attached HDMI display on or off where the attached monitor supports this feature.

The screenshot shows the 'datavideo' web interface. At the top right, there are navigation links for 'Home', 'Settings' (which is highlighted), 'Stats', and 'Logout (admin)'. Below the navigation bar is a sidebar menu with the following items: 'AUD Audio Setup', 'VID Display Setup', 'NET Network Setup', 'LIVE Live Stream Setup', 'CLD Cloud', 'A/C Account Setup', 'STB STB Mode', and 'CEC CEC Control'. The main content area shows 'CEC Mode' set to 'Normal' with a dropdown arrow, and a 'Save Settings' button. Below this, there are two power icons (one lit, one unlit) and a message bar that reads 'CEC 'standby' command was sent to display'.



CEC 'on' command was sent to display



CEC 'standby' command was sent to display

**Note:** The CEC feature needs to be enabled in the attached monitor settings as well as on the NVD-40.



## Settings > Plugins

This page allows you to upload a .zip file containing the latest plugins for **Video Sharing & HLS** mode, this function should only be used if you are instructed to do so by a Datavideo support representative.

## Settings > Cloud


Cloud mode allows the NVD-40 to be connected to dv Cloud (<https://www.dvcloud.tv>) and offers the following features:

- Control the NVD-40 settings from anywhere over the internet
- Monitor the NVD-40 from anywhere over the internet
- Easily link the NVD-40 to encoders via the cloud
- Use SRT (secure reliable transport) for reliable low latency point to point links over the internet

### Connect the NVD-40 to dv Cloud

You must have a dv Cloud subscription to use this feature, please visit <https://www.dvcloud.tv> to sign up.

First enable cloud operation then enter your dv Cloud username (the email address you used when you signed up) and password and click 'Save Changes'



The screenshot shows the 'Configure Cloud Operation' section of the Datavideo NVD-40 settings interface. On the left is a navigation menu with buttons for 'AUD Audio Setup', 'VID Display Setup', 'NET Network Setup', 'LIVE Live Stream Setup', and 'CLD Cloud'. The main content area is titled 'Configure Cloud Operation' and includes a 'dvCloud Mode' section with a 'Cloud Operation' dropdown set to 'Enabled'. Below this are input fields for 'dvCloud Username' (containing 'user@domain.com') and 'dvCloud Password' (masked with dots). A message states 'Failed to find servers or your credentials are invalid!' and a 'Save Changes' button is at the bottom.

Next select the dv Cloud server you wish to connect to and optionally give the decoder a name (for example "NVD-40"). If you do not set a device name, the decoder's serial number NVD-40-1000000032022281 will be used.

dvCloud Mode

### Configure Cloud Operation

Please visit [dvcloud.tv](http://dvcloud.tv) for more information

Cloud

Operation

dvCloud

Username

dvCloud

Password

dvCloud


Servers

Device Name


Click 'Save Changes', the NVD-40 should now be connected to dv cloud.

### Control via dv Cloud

Select 'Decoders' from the 'Hardware' menu.




You will see the NVD-40 listed as shown below.



The screenshot shows the dv Cloud interface with a navigation menu at the top: Sources, Recordings, Stats, Access, Hardware, Settings, Help, and Logout (admin). Below the menu is a search bar. The main content is a table with the following columns: Name, Link, Status, Packets Read, Channel, and Restart. The table lists three decoders: NVD-35.MK2-1AF6203B (Down, Not Decoding, 0 packets), NVD-30.MK2-E3FBA84C (Down, Not Decoding, 0 packets), and NVD-40 (Up, Not Decoding, 0 packets). Each row has a restart button. The footer shows the version 1.12ubuntu63 /r30(c67/67).

Name	Link	Status	Packets Read	Channel	Restart
NVD-35.MK2-1AF6203B	Down	Not Decoding	-	-	
NVD-30.MK2-E3FBA84C	Down	Not Decoding	-	-	
NVD-40	Up	Not Decoding	0	-	

Click the decoder's name to access its settings remotely.




The screenshot shows the settings page for decoder NVD-45-100000032022281. The page has the same navigation menu as the previous screenshot. The settings are as follows: Decoder Name: NVD-45-100000032022281; Output To: HDMI/SDI(Digital); Output Resolution: 1080p 59.94(NTSC); Rotate / Flip: Off; Buffer Size: 0.50 s; SRT Latency: 120; Assigned To Channel: -. There is a 'Save Changes' button at the bottom left. The footer shows the version 1.12ubuntu63 /r30(c67/67).


### Link to a live channel on dv Cloud

For help with setting up your encoder with dv Cloud, please see the separate support material on <https://www.datavideo.info/>.

Click on the video source name.




Select the 'Hardware Decoders' tab under 'Add your streaming destinations'




Select the check box next to the decoder you wish to link and then save the settings.

You will see the NVD-40 is now linked to the channel NVS-40 on the 'Decoders' page.



You can monitor the decoders status from the 'Stats' page.




The screenshot displays two decoder status cards. The left card is titled 'NVS-40' and lists the following specifications: Video Codec: H264, Width: 1280, Height: 720, Audio Codec: AAC, Channels: 2, and Input Data Rate: 1704.72kbps. The right card is titled 'Studio One' and shows 'FPS: 30' next to a green status indicator. A blue vertical button with two white left-pointing chevrons is positioned between the two cards.

## Automatic Firmware Updates

The NVD-40 features an automatic update system to avoid the need for the user to have to manually install firmware upgrades.

The NVD-40 will automatically check for updates whenever it is connected to the internet.

You will be notified if an update is available; a message will appear at the top of the interface. Simply click the 'Initiate Update' link to start the process, you can monitor the status of the update from the 'Stats' tab.



## Datavideo NVD-40 Socket Commands

Using third party applications, users can easily connect to the NVD-40 using Telnet. To establish a connection with the NVD-40 simply open a Telnet connection to the NVD units IP address on port 23.

**Please Note:** Socket commands are disabled by default, to enable socket commands please check the appropriate option in the 'Network Tab'.

The NVD unit has three responses to commands:

**FAILED:** shows that the command could not be executed successfully.

**OK:** shows that the command is executed without any problem.

**Invalid Command:** shows that the command was not recognized.

The control commands are as follows:

**Load [URL]** An example of this command would be

Load "rtsp://192.168.1.1/stream1"  
OK

**On** Sends CEC on command (NVD-40 Only)

**Off** Sends CEC off command (NVD-40 Only)

**Reboot** Restarts the unit

**Status** Prints the current status  
(Stream URL & Display information)

## Port Forwarding on your firewall / router


So that an NVS-33/34/35/40 video stream can be seen on the internet (beyond the default gateway), certain network related 'ports' should be opened on your router or firewall. Your local network administrator or I.T. support should be able to help you with this.

Enable the "port forwarding" function or open below ports within the router settings.

Web Server/HLS	RTSP	RTMP
80	8554 (over TCP)	1935 (RTMP)
	8000 (over HTTP)	8080 (RTMPT)
	8080 (over HTTP)	8081 (RTMPS)



## Dimensions



## Specifications

<b>Interface</b>	
Audio/Video Input	RJ-45 Female (10/100M Ethernet) x 1 DHCP/Static IP
Video Output	HDMI 2.0 x 1 (Digital) Composite x 1 (Analogue)
Audio Output	RCA (L/R) x 2 HDMI embedded audio
Indicator	Power LED x 1, LAN LED x 2 (Active, Connection)
USB	1
IR Receiver	Yes
Reset Button	Yes
Power Supply	DC 12V
<b>Standards</b>	
Video Resolution	3840x2160p: 60/59.94/50/30/29.97/25/24/23.98 (H.265 Only) 1080p: 60/59.94/50/30/29.97/25/24/23.98 1080i: 60/59.94/50, 720p: 60/59.94/50 480i 60 NTSC, 576i 50 PAL
Streaming Protocol	RTSP over UDP (Unicast / Multicast) RTSP over TCP RTSP over HTTP SRT (Secure Reliable Transport) caller MPEG-TS over UDP RTMP Pull RTMP Push (Internal Server) UDP raw (Unicast/Multicast) HLS over HTTP MPEG-TS over TCP Pull Supported video sharing websites
Audio Sample Rate	48 kHz

---

<b>General</b>	
Control	Web browser UI for configuration and control TCP/IP Socket commands
Update	Automatic firmware upgrade
Operating Temperature	0°C to 40°C (32°F to 104°F)
Storage Temperature	-20°C to 60°C (-4°F to 140°F)
Humidity	10% to 80% (non-condensing)
Power Consumption	12V / 7.2W
Dimensions (mm)	220 x 143.3 x 42
Weight	1.0 Kg

## Service & Support

It is our goal to make your products ownership a satisfying experience. Our supporting staff is available to assist you in setting up and operating your system. Please refer to our web site [www.datavideo.com](http://www.datavideo.com) for answers to common questions, support requests or contact your local office below.

Please visit our website for latest manual update.  
<https://www.datavideo.com/product/NVD-40>

**datavideo**  
[www.datavideo.com](http://www.datavideo.com)



@DatavideoUSA @DatavideoIndia2016  
@DatavideoEMEA @Datavideojapan  
@DatavideoTaiwan @DatavideoLatam  
@DatavideoAsia @DatavideoBrasil



@Datavideo  
@Datavideo\_EMEA  
@Datavideo\_Taiwan



@DatavideoUSA  
@DVTWDVCN



@DatavideoUSA  
@DatavideoEurope

All the trademarks are the properties of their respective owners.  
Datavideo Technologies Co., Ltd. All rights reserved 2020

Aug-23-2022  
Ver.: E1