

SHOWVEN®

USER MANUAL CIRCLE FLAMER X-F3600

V1.2



Showven Technologies Co.,Ltd.

CIRCLE FLAMER X-F3600

USER MANUAL

★ Please read this manual carefully before operating this product.

★ Warranty card attached in the manual, please keep it well.

▲ WARNING

- Unauthorized repair are prohibited, it may cause serious incident.
- Make sure power supply is consistent with the rated voltage of the equipment, and the socket must be well grounded. Unplug and turn off the machine when not in use.
- Before connecting the power cable, communication DMX cable should be well connected and ensure the command keeps at firing OFF status. And safety lock stays at test mode.
- The device can only be placed horizontally. Safety distances are marked on the device (at least 15m in all projection directions, at least 5m to the other sides of the device).
- After turning on the device, no person is allowed to stay in the danger area. Ensure all persons that are part of the show are informed about the safety distance, risks and functions of the device.
- Always have a CO2 fire extinguisher and an extinguishing blanket in case of need.
- If there is any doubt as to the safety operation of the device in any circumstances, the device should be taken out of service immediately. Be sure the device is in good operating condition before use. If it fails to fire correctly, immediately shut down and check it accordingly.
- Be sure to use high quality flame fluid, otherwise, it is easily led to failure or danger. Be careful when refilling the flame fluid tank. Please keep flame fluid away from heat source, sparks, fire or other possibility of ignition. Do not smoke!
- The operator responsible for the control of Circle Flamer must always have a clear view of the device, so that he/she can stop the show immediately when there is danger. The main AC power switch should be near the operator. So that the operator can turn off the power of all devices in case of abnormal.
- The device shall not be altered and applied to other use purposes.
- Notes for use of Battery power supply: CIRCLE FLAMER with stable internal circuit design, please support X-F3600 with battery voltage higher than 12V. The driving speed of the motor won't change because of the decrease of battery power supply. Battery options: 12V lead-acid battery (above 30AH, with more than 24h standby). For Lithium battery, please use battery with output above 30A. Socket type: NEUTRIK-NL4FX, 4 pin sound couplers (1+ connect 12V anode, 1- connect 12V cathode). Connecting power cables should be above 14AWG.
- Nozzle Protection Cover of X-F3600 should be removed before power-on, otherwise the rotating mechanism of the equipment will be damaged. The Nozzle Protection Cover is only used during transportation.
- The firing nozzle of X-F3600 is strictly forbidden to rotate over $\pm 90^\circ$ manually in case of power-off, otherwise the rotating mechanism of the equipment will be damaged.

▲ Foreword

Thanks for choosing SHOWVEN CIRCLE FLAMER X-F3600. Please read the following manual carefully and completely before operating this product. Operating according to instructions is very important for safety, and can prolong the service life of the machine.

Strictly follow the instructions in the manual when operating Circle Flamer X-F3600. If you have any doubts, please contact SHOWVEN technologies Co., Ltd by info@showven.cn.

We assume the person who uses or comes in contact with the device are familiar with how the device should be handled.

This includes proper use, maintenance and repair of the machine as defined in this user manual.

Disclaimers:

SHOWVEN technologies Co., Ltd excludes liability for unsafe situations, accidents and damages resulting from:

1. Ignoring warnings or regulations as shown on circle flamer or this manual.
2. Use for other applications or circumstances other than those indicated herein.
3. Changes to the circle flamer, including use of non-original spare parts.
4. Removed safety cover without authorization from SHOWVEN.
5. Use this machine by unqualified or untrained personnel.
6. Improper use of machine.

▲ Functional Characteristics


- Compact pumping system ensure compact size of machine.
- Double electromagnetic valves design for additional safety.
- Tilt protection, the tilt sensor will be activated when machine slant Over 45° .
- Unique safety lock design, device can't firing when locked, avoid spurious triggering.
- Intelligent control system: pressure monitoring, safety warning, no fuel alarming, system failure warning etc.
- High performance nozzle, reliable and durable.
- High-accuracy rotating head driving and controlling system, allows for fast and precise flame bursts.
- Strengthened and rustproof metal panel, water-proof design.
- Neutrik PowerCON TRUE1 and DMX socket.
- Standard battery connector configuration, support 12V battery power supply.
- Fitted with fireworks igniter signal port, can be triggered by fireworks igniter.
- Flame effects up to 8-10m (no wind), with maximum rotation of 3 cycles.
- As much as 160 preset flame sequences are available. It is easier and stable to running the CIRCLE FLAMER when controlled by SHOWVEN original host controller ZK6200/ZK6300.

▲ Technical Specifications


MODEL	Circle Flamer X-F3600
Rotation Mode Switch	FULL CIRCLE MODE / HALF CIRCLE MODE
Dimension	640 x 360 x 370mm
Input	AC100-240V, 50-60Hz
Work power	380W
Interface	Double DMX Interface; 9V-60V Fireworks igniter signal port
Control	Standard DMX
Effect Maximum Height	8-10m (no wind)
Effect Angles	1080° (up to 3 cycles)
Fuel	ISOPROPANOL, ISOPAR G,H,L,M, BIOETHANOL
Fuel Bottle Capacity	10L
Weight (no fuel)	30Kg
Fuel Consumption Rate	60ml/s

▲ Structure of Circle Flamer

1. Nozzle Protection Cover
2. Firing Nozzle
3. Top Panel
4. Fuel Bottle Area
5. Control Panel
6. Safety Loop



- Connection dimension diagram of bottom bracket of the flamer




▲ Overview of Control Panel

1. LCD screen operate panel
2. Safety Lock
3. Indicator Light
4. DC 5V output
5. 3-pin DMX socket
6. 5-pin DMX socket
7. 110V/220V Power socket
8. Fuse
9. ON/OFF switch
10. 12V Battery socket
11. DC 9V-60V fireworks igniter signal port



▲ Operation Panel



1. LED Display Area

RX: Radio receiving (reserved);

DMX: DMX signal. Flash means DMX signal available, otherwise no DMX signal;

ERR: Light on when there is an error;

PUMP: Light on when pump is running.

2. Button Functions:

MENU: Switch interface to setup parameter;

+: Parameter Up;

-: Parameter Down;


ENTER: Confirm and save parameters (screen will flash when parameters saved);

Note: screen display will switch to main interface if don't press button for a long time.

3. Welcome Interface

First Line: Product model and software version number;


Second Line: Equipment factory number.



4. Main Interface

First Line: Rotation Mode (Full Cycle Mode(360) or Half Cycle Mode(180)); DMX address;

Second Line: Pressure100 (e.g. 100=10bar); V: 13.6 means internal voltage is 13.6V.



5. Alert Message

Alert Message	Explanation
E0 System Lock	Safety lock located at TEST MODE.
E1 Pressure Err	Pressuriser for about 13s, pressure value failed to reach 100%, system will report E1. Possible fault: No fuel, pump failure, pipeline problem etc.
E2 P Relief Err	Pipeline can't release pressure leads to pressure relief error. Possible fault: pressure release valve failure, pipeline problem or control system problem etc.
E3 Motor Err	Motor fault Possible fault: swiveling nozzle stuck, motor failure etc.
E4 Ext Ignition	When Ext Ignite is ON, device will pressuriser automatically when switch safety lock to USER MODE; decompression when switch to TEST MODE. 9V-60V fireworks ignitor signal will trigger related firing sequences.
E5 Voltage Err	Battery voltage > 15V or < 10V for continuous 5s, machine stops running. Possible fault: the battery is low.
E6 Tip Err	if the machine slant over 45° , it stops running, system will report E6.
E7 Factory Mode	DMX signal blocked in factory mode.

6. Interface setup

Press "MENU" to switch through setup menu.

Menu	Range	Explanation
Set DMX Address	1~512	DMX address setup
Angle Limit	Full Cycle Mode (360)/ Half Cycle Mode (180)	Restrict nozzle rotate angles
Angle Limit Note: Angle limit activate under half cycle mode	MIN: NO.1-NO.15 MAX: NO.1-NO.15	Restrict nozzle rotate angles: Set by "+" and "-", and confirm by "ENTER"

7. Advanced Interface


Press "MENU" 3s enter advanced interface, press "MENU" to switch interface, press "MENU" 3s can back to main interface.

Items	Contents	Description
Drive Test	OFF / Motor/ Pump / Igniter / Relief Valve / Jet Valve	
	1. Motor	Swiveling and stop at target angle.
	2. Pump	Pump running 1s, if pressure reached the target value, the pump will not running.
	3. Igniter	Ignite 1s
	4. Relief Valve	Release pressure 1s
	5. Jet Valve	Safety lock located at user mode, release pressure for 5s, open jet valve and close to check the working status of jet valve.
Ext Ignite	ON / OFF	Trigger through 5-60V fireworks ignitor signal
Set Ext Sequence	Full Cycle Mode: 1~94 Half Cycle Mode: 1~70	Preset sequence triggered by fireworks ignitor
Language	Chinese / English	Language switch
Mode Select	Factory Mode / Normal Mode	Factory mode is for test in factory only
Tip Setting	ON / OFF	Turn ON/OFF tip over function
Reset Parameter	YES / NO	Reset default parameter settings

▲ Operation Instructions

1. Direction explanation

Please read the safety distance print on the top panel of CIRCLE FLAMER carefully.















- (1) 1 to 15 is the firing angle when Circle flamer running in half cycle mode.
- (2) AMGS is the firing direction when running in full cycle mode, A is downward, M is upward, G is left side, S is right side. For more detail please refer to angle definition in under full cycle mode.
- (3) Audience side and control side are indicated in above picture.
- (4) Safety distances for CIRCLE FLAMER are indicated in above picture. At least 15m in all projection directions, at least 5m to the other sides of the device.



Note: in order to indicate correct direction, please place the top panel correctly.

2. Quick Operation Sheet

Immediately upon receiving the machine, carefully unpack the carton, check the machine received in good condition. Ensure safety operation of machine, please do following below operation procedures when operate CIRCLE FLAMER.

Operation step	Schematic diagram and explanation	Explanation
1. Installation	The device can only be placed horizontally, if placed on truss, please locked with extra safety ropes, Remove nozzle protection cover if it exist.	
2. Locate safety lock at TEST MODE		Before operate machine please locate safety lock at TEST MODE. TEST MODE: operator can test the rotate of nozzle, but the fuel ejection function disabled, so there is no fuel eject and flames. USER MODE: the device can generate flames normally. Please strictly follow the safety distance requirement, remove all human, animal or flammable objects in the danger area.
3. Fueling		Please fueling with high quality fuel according to requirement of this manual.
4. Power and DMX cable connection		Two kind of power supply optional: 1. 110V/220V main power supply 2. 12V battery power supply
5. Switch ON the machine		Please confirm safety lock located at TEST MODE before switch on the POWER ON/OFF.


6. Set DMX address		CIRCLE FLAMER occupy 6 channels. Detail information please refer to the table of page18.
7. Pressuriser		Host controller: Press "pre-heat" button (light on). DMX console: switch DMX value of channel 6 to 50-200.
8. Check device status in TEST MODE		Reconfirm safety lock located at TEST MODE before test. In this status, the nozzle will rotate, and igniter will activated, but there is no flame. When use DMX console to test the sequence, suggest to set CH1 at 128, so that nozzle stay at straight up position after each sequence.
9. Pressure Relief		Host controller: Press "pre-heat" key (light off). DMX console: switch DMX value of channel 6 to 0-49/201-255.
10. Switch safety lock to USER MODE		Before switch to USER MODE, Please strictly follow the safety distance requirement, remove all human, animal or flammable objects in the danger area.
11. Pressuriser		Host controller: Press "pre-heat" button (light on). DMX console: switch DMX value of channel 6 to 50-200.
12. Firing		Set firing sequence Host controller: Press "FIRING" key. DMX console: switch DMX value of channel 3 to 254-255.
13. Pressure Relief		Relief pressure when show finished or CIRCLE FLAMER not use for a long period. Host controller: Press "pre-heat" key (light off). DMX console: switch DMX value of channel 6 to 0-49/201-255.

<p>14. Switch safety lock to TEST MODE</p>		<p>Guarantee safety use for next time.</p>
<p>15. Power off</p>		<p>Power off CIRCLE FLAMER, tear down power cable and DMX cable, pack up the device when it is cooled down.</p>

3. Full Cycle Mode

(1) Angle definitions

CIRCLE FLAMER with 360° projection angles, below schematic shows firing angles from Audience Side view. 1080°(360°X3) divided into 72 projection directions, the angle NO. as below:



(2)Drive time

Neighbouring injection angles take 20 ms to reach. For example, the nozzle drive from A1 to B1, it takes 20ms. when opera-tor design a show to synchronize to music, this drive time must be calculated.

The following table shows the time of the nozzle reaching the required angle from NO.A1:

No.	Angles	Drive time needed
NO.A1	0°	0ms
NO.B1	15°	20ms
NO.C1	30°	40ms
NO.D1	45°	60ms
NO.E1	60°	80ms
NO.F1	75°	100ms
NO.G1	90°	120ms
NO.H1	105°	140ms
NO.I1	120°	160ms
NO.J1	135°	180ms
NO.K1	150°	200ms
NO.L1	165°	220ms
NO.M1	180°	240ms
NO.N1	195°	260ms
NO.O1	210°	280ms
NO.P1	225°	300ms
NO.Q1	240°	320ms
NO.R1	255°	340ms
NO.S1	270°	360ms
NO.T1	285°	380ms
NO.U1	300°	400ms
NO.V1	315°	420ms
NO.W1	330°	440ms
NO.X1	345°	460ms
NO.A2	360°	480ms
NO.B2	375°	500ms
NO.C2	390°	520ms
NO.D2	405°	540ms
NO.E2	420°	450ms
...
NO.A3	720°	960ms
...
E(END)	1080°	1440ms

(3)Sequence list

Circle Flamer X-F3600 with more than 160 kind of preset firing sequences, 94 kind of firing sequences under full cycle mode. Operator use related channel DMX value or sequence No. to access certain sequence. Sequence list as below:

Single Ignition Sequence List

Sequence No.	Ignition angle NO.	Description	Nozzle Movement	Firing Duration	CH5 DMX Reference Value
1	A2	Single Ignition SHORT flame	Static	0.11s	3-5
2	B2	Single Ignition SHORT flame	Static	0.11s	6-7
3	C2	Single Ignition SHORT flame	Static	0.11s	8 10
4	D2	Single Ignition SHORT flame	Static	0.11s	11-12
5	E2	Single Ignition SHORT flame	Static	0.11s	13-15
6	F2	Single Ignition SHORT flame	Static	0.11s	16-17
7	G2	Single Ignition SHORT flame	Static	0.11s	18-20
8	H2	Single Ignition SHORT flame	Static	0.11s	21-22
9	I2	Single Ignition SHORT flame	Static	0.11s	23-25
10	J2	Single Ignition SHORT flame	Static	0.11s	26-28
11	K2	Single Ignition SHORT flame	Static	0.11s	29-30
12	L2	Single Ignition SHORT flame	Static	0.11s	31-33
13	M2	Single Ignition SHORT flame	Static	0.11s	34-35
14	N2	Single Ignition SHORT flame	Static	0.11s	36-38
15	O2	Single Ignition SHORT flame	Static	0.11s	39-40
16	P2	Single ignition SHORT flame	Static	0.11s	41-43
17	Q2	Single ignition SHORT flame	Static	0.11s	44-45
18	R2	Single ignition SHORT flame	Static	0.11s	46-48
19	S2	Single ignition SHORT flame	Static	0.11s	49-50
20	T2	Single ignition SHORT flame	Static	0.11s	51-53
21	U2	Single ignition SHORT flame	Static	0.11s	54-56
22	V2	Single ignition SHORT flame	Static	0.11s	57-58
23	W2	Single ignition SHORT flame	Static	0.11s	59-61
24	X2	Single ignition SHORT flame	Static	0.11s	62-63
25	A2	Single Ignition LONG flame	Static	0.56s	64-66
26	B2	Single Ignition LONG flame	Static	0.56s	67-68
27	C2	Single Ignition LONG flame	Static	0.56s	69-71
28	D2	Single Ignition LONG flame	Static	0.56s	72-73
29	E2	Single Ignition LONG flame	Static	0.56s	74-76
30	F2	Single Ignition LONG flame	Static	0.56s	77-79
31	G2	Single ignition LONG flame	Static	0.34s	80-81
32	H2	Single ignition LONG flame	Static	0.34s	82-84
33	I2	Single ignition LONG flame	Static	0.34s	85-86
34	J2	Single ignition LONG flame	Static	0.34s	87-89
35	K2	Single ignition LONG flame	Static	0.34s	90-91
36	L2	Single ignition LONG flame	Static	0.34s	92-94
37	M2	Single ignition LONG flame	Static	0.34s	95-96

38	N2	Single ignition LONG flame	Static	0.34s	97-99
39	O2	Single ignition LONG flame	Static	0.34s	100-101
40	P2	Single ignition LONG flame	Static	0.34s	102-104
41	Q2	Single ignition LONG flame	Static	0.34s	105-107
42	R2	Single ignition LONG flame	Static	0.34s	106-110
43	S2	Single ignition LONG flame	Static	0.34s	111-112
44	T2	Single ignition LONG flame	Static	0.34s	113-114
45	U2	Single ignition LONG flame	Static	0.34s	115-117
46	V2	Single ignition LONG flame	Static	0.34s	118-119
47	W2	Single ignition LONG flame	Static	0.34s	120-121
48	X2	Single ignition LONG flame	Static	0.34s	122-124

Step Sequences List

Sequence No.	Ignition angle NO.	Description	Nozzle Movement	Firing Duration	CH5 DMX Reference Value
49	Step from M2-M3	30°- 1cycle - SHORT flame	Clockwise	2.04s	125-127
50	Step from M2-M1	30°- 1cycle - SHORT flame	Anticlockwise	2.04s	128-130
51	Step from M2-M3	45°- 1cycle - SHORT flame	Clockwise	1.25s	131-132
52	Step from M2-M1	45°- 1cycle - SHORT flame	Anticlockwise	1.34s	133-135
53	Step from M2-A3	30°- 1.5 cycle - SHORT flame	Clockwise	3.04s	136-137
54	Step from M2-A1	30°- 1.5 cycle - SHORT flame	Anticlockwise	3.04s	138-140
55	Step from M2-A3	45°- 1.5cycle - SHORT flame	Clockwise	2.2s	141-142
56	Step from M2-A1	45°- 1.5cycle - SHORT flame	Anticlockwise	2.2s	143-145
57	Step from A1-E	30°- 3cycle - SHORT flame	Clockwise	6.80s	146-147
58	Step from E-A1	30°- 3cycle - SHORT flame	Anticlockwise	6.80s	148-150
59	Step from A1-E	45°- 3cycle - SHORT flame	Clockwise	4.8s	151-152
60	Step from E-A1	45°- 3cycle - SHORT flame	Anticlockwise	4.8s	153-155
61	Step from A1-E	Accelerate-3 cycles - SHORT flame	Clockwise	8.1s	156-158
62	Step from E-A1	Accelerate-3 cycles - SHORT flame	Anticlockwise	8.1s	159-160
63	Step from A1-E	Decelerate-3 cycles - SHORT flame	Clockwise	8.1s	161-163
64	Step from E-A1	Decelerate-3 cycles - SHORT flame	Anticlockwise	8.1s	164-165
65	Step from M2<>M3	Back and forth-4cycles-SHORT flame	C>AC>C>AC	5.4s	166-168
66	Step from M2<>M1	Back and forth-4cycles-SHORT flame	AC>C >AC>C	5.4s	169-170

Wave Sequence List

Sequence No.	Ignition angle NO.	Description	Nozzle Movement	Firing Duration	CH5 DMX Reference Value
67	Wave M2-->M3	Clover shape wave-1cycle	Clockwise	2.37s	171-173
68	Wave M2-->M1	Clover shape wave-1cycle	Anticlockwise	2.37s	174-175
69	Wave M2-->M3	Fast-1cycle	Clockwise	0.83s	176-178
70	Wave M2-->M1	Fast-1cycle	Anticlockwise	0.83s	179-181
71	Wave M2-->M3	Slow-1cycle	Clockwise	1.27s	182-183
72	Wave M2-->M1	Slow-1cycle	Anticlockwise	1.27s	182-186
73	Wave M2-->A3	Fast-1.5cycle	Clockwise	1.17s	187-188
74	Wave M2-->A1	Fast-1.5cycle	Anticlockwise	1.17s	189-191
75	Wave M2-->A3	Slow-1.5cycle	Clockwise	1.9s	192-193
76	Wave M2-->A1	Slow-1.5cycle	Anticlockwise	1.9s	194-196
77	Wave A1-->E	Fast-3cycle	Clockwise	2.88s	197-198
78	Wave E-->A1	Fast-3cycle	Anticlockwise	2.88s	199-201


Additional Sequences List

Sequence No.	Ignition angle NO.	Description	Nozzle Movement	Firing Duration	CH5 DMX Reference Value
79	Step from F2-T2	15°- SHORT flame Step sequence	L->R	2.6s	202-203
80	Step from T2-F2	15°- SHORT flame Step sequence	R->L	2.6s	204-206
81	Step I2-K2-M2-O2-Q2	30°- SHORT flame Step sequence	L->R	1.25s	207-209
82	Step Q2-O2-M2-K2-I2	30°- SHORT flame Step sequence	R->L	1.25s	210-211
83	Step J2-M2-Q2	45°- SHORT flame Step sequence	L->R	0.9s	212-214
84	Step Q2-M2-J2	45°- SHORT flame Step sequence	R->L	0.9s	215-216
85	Step K2-O2	60°- SHORT flame Step sequence	L->R	0.6s	217-219
86	Step O2-K2	60°- SHORT flame Step sequence	R->L	0.6s	218-221
87	Wave J2-->P2	Middle wave sequence	L->R	3.5s	222-224
88	Wave P2-->J2	Middle wave sequence	R->L	3.5s	225-226
89	Wave F2-->M2	SHORT wave sequence	L->R	4.3s	227-229
90	Wave T2-->M2	SHORT wave sequence	R->L	4.3s	230-232
91	Wave F2-->T2	LONG wave sequence	L->R	8.5s	233-234
92	Wave T2-->F2	LONG wave sequence	R->L	8.5s	235-237
93	Step from I2<>Q2	30°- SHORT flame Step sequence	L->R->L->R->L	5s	238-239
94	Step from Q2<>I2	30°- SHORT flame Step sequence	R->L->R->L->R	5s	240-242

4. Half Cycle Mode

(1) Angle definitions

In half cycle mode, CIRCLE FLAMER X-F3600 with firing angle of $\pm 105^\circ$, below schematic shows firing angles from Audience Side view. $\pm 105^\circ$ divided into 15 projection directions as below:



(2) Drive time

Time needed for the motor drive from NO.8 to relevant angle.

No.	Angles	Drive time needed
NO.1	-105°	170ms
NO.2	-90°	150ms
NO.3	-75°	130ms
NO.4	-60°	110ms
NO.5	-45°	90ms
NO.6	-30°	70ms
NO.7	-15°	50ms
NO.8	0°	0ms
NO.9	15°	50ms
NO.10	30°	70ms
NO.11	45°	90ms
NO.12	60°	110ms
NO.13	75°	130ms
NO.14	90°	150ms
NO.15	105°	170ms

For example for the motor drive from 0° to 45° , it need 90ms, when operator design a show to synchronize to music, this drive time must be calculated.

(3)Sequence list

Circle Flamer X-F3600 with more than 160 kind of preset firing sequences, 70 kind of firing sequences under half cycle mode. Operator use related channel DMX value or sequence No. to access certain sequence. Sequence list as below:

Single Ignition Sequence List

Sequence No.	Ignition angle NO.	Ignition angle NO.	Description	Nozzle Movement	Firing Duration	CH5 DMX Reference Value
1	NO.1	-105°	Single Ignition SHORT flame	Static	0.19s	3-5
2	NO.2	-90°	Single Ignition SHORT flame	Static	0.19s	6-7
3	NO.3	-75°	Single Ignition SHORT flame	Static	0.19s	8-10
4	NO.4	-60°	Single Ignition SHORT flame	Static	0.19s	11-12
5	NO.5	-45°	Single Ignition SHORT flame	Static	0.19s	13-15
6	NO.6	-30°	Single Ignition SHORT flame	Static	0.19s	16-17
7	NO.7	-15°	Single Ignition SHORT flame	Static	0.19s	18-20
8	NO.8	0°	Single Ignition SHORT flame	Static	0.19s	21-22
9	NO.9	15°	Single Ignition SHORT flame	Static	0.19s	23-25
10	NO.10	30°	Single Ignition SHORT flame	Static	0.19s	26-28
11	NO.11	45°	Single Ignition SHORT flame	Static	0.19s	29-30
12	NO.12	60°	Single Ignition SHORT flame	Static	0.19s	31-33
13	NO.13	75°	Single Ignition SHORT flame	Static	0.19s	34-35
14	NO.14	90°	Single Ignition SHORT flame	Static	0.19s	36-38
15	NO.15	105°	Single Ignition SHORT flame	Static	0.19s	39-40
16	NO.1	-105°	Single ignition LONG flame	Static	0.56s	41-43
17	NO.2	-90°	Single ignition LONG flame	Static	0.56s	44-45
18	NO.3	-75°	Single ignition LONG flame	Static	0.56s	46-48
19	NO.4	-60°	Single ignition LONG flame	Static	0.56s	49-50
20	NO.5	-45°	Single ignition LONG flame	Static	0.56s	51-53
21	NO.6	-30°	Single ignition LONG flame	Static	0.56s	54-56
22	NO.7	-15°	Single ignition LONG flame	Static	0.56s	57-58
23	NO.8	0°	Single ignition LONG flame	Static	0.56s	59-61
24	NO.9	15°	Single ignition LONG flame	Static	0.56s	62-63
25	NO.10	30°	Single ignition LONG flame	Static	0.56s	64-66
26	NO.11	45°	Single Ignition LONG flame	Static	0.56s	67-68
27	NO.12	60°	Single Ignition LONG flame	Static	0.56s	69-71
28	NO.13	75°	Single Ignition LONG flame	Static	0.56s	72-73
29	NO.14	90°	Single Ignition LONG flame	Static	0.56s	74-76
30	NO.15	105°	Single Ignition LONG flame	Static	0.56s	77-79

Step Sequences List

Sequence No.	Ignition angle NO.	Description	Nozzle Movement	Firing Duration	CH5 DMX Reference Value
31	Step from 1-15	SHORT flame Step sequence	Clockwise	2.04s	125-127
32	Step from 15-1	SHORT flame Step sequence	Anticlockwise	2.04s	128-130
33	Step 5-8-11	SHORT flame Step sequence	Clockwise	1.25s	131-132
34	Step 11-8-5	SHORT flame Step sequence	Anticlockwise	1.34s	133-135
35	Step 6-10	SHORT flame Step sequence	Clockwise	3.04s	136-137
36	Step 10-6	SHORT flame Step sequence	Anticlockwise	3.04s	138-140
37	Step 4-6-8-10-12	SHORT flame Step sequence	Clockwise	2.2s	141-142
38	Step 12-10-8-6-4	SHORT flame Step sequence	Anticlockwise	2.2s	143-145
39	Step 8-6-10-4-12	SHORT flame Step sequence	Clockwise	6.80s	146-147
40	Step 8-10-6-12-4	SHORT flame Step sequence	Anticlockwise	6.80s	148-150
41	Step from 1-15	LONG flame Step sequence	Clockwise	4.8s	151-152
42	Step from 15-1	LONG flame Step sequence	Anticlockwise	4.8s	153-155
43	Step 5-8-11	LONG flame Step sequence	Clockwise	8.1s	156-158
44	Step 11-8-5	LONG flame Step sequence	Anticlockwise	8.1s	159-160
45	Step 6-10	LONG flame Step sequence	Clockwise	8.1s	161-163
46	Step 10-6	LONG flame Step sequence	Anticlockwise	8.1s	164-165
47	Step 4-6-8-10-12	LONG flame Step sequence	C>AC>C>AC	5.4s	166-168
48	Step 12-10-8-6-4	LONG flame Step sequence	AC>C >AC>C	5.4s	169-170
49	Step 8-6-10-4-12	LONG flame Step sequence	C>AC>C>AC	5.4s	166-168
50	Step 8-10-6-12-4	LONG flame Step sequence	AC>C >AC>C	5.4s	169-170

Wave Sequence List

Sequence No.	Ignition angle NO.	Description	Nozzle Movement	Firing Duration	CH5 DMX Reference Value
51	Wave 5-->11	Middle wave sequence	L->R	1.99s	131-132
52	Wave 11-->5	Middle wave sequence	L->R	1.99s	133-135
53	Big wave 1-->15	LONG wave sequence	L->R	4.14s	136-137
54	Big wave 15-->1	LONG wave sequence	R->L	4.14s	138-140
55	Wave 8-->1	Middle wave sequence	M->L	2.18s	141-142
56	Wave 8-->15	Middle wave sequence	M->R	2.18s	143-145
57	Wave 1-->8	Middle wave sequence	L->M	2.16s	146-147
58	Wave 15-->8	Middle wave sequence	R->M	2.16s	148-150
59	Wave 8-->11	SHORT wave sequence	M->R	1.12s	151-152
60	Wave 8-->5	SHORT wave sequence	M->L	1.12s	153-155
61	Wave 5-->8	SHORT wave sequence	L->M	1.24s	156-158
62	Wave 11-->8	SHORT wave sequence	R->M	1.24s	159-160

Additional Sequences List

Sequence No.	Ignition angle NO.	Description	Nozzle Movement	Firing Duration	CH5 DMX Reference Value
63	Step 2-14	SHORT flame Step sequence	L->R	0.60s	161-163
64	Step 14-2	SHORT flame Step sequence	R->L	0.60s	164-165
65	Step 2-14	LONG flame Step sequence	L->R	1.38s	166-168
66	Step 14-2	LONG flame Step sequence	R->L	1.38s	169-170
67	Step 8-14	SHORT flame Step sequence	M->L	1.85s	171-173
68	Step 8-2	SHORT flame Step sequence	M->R	1.85s	174-175
69	Step 8-14	LONG flame Step sequence	M->L	4.18s	146-147
70	Step 8-2	LONG flame Step sequence	M->R	4.18s	148-150

5. DMX Control

Channel	Function
CH1	Manual Angle setup: (1) Full Cycle Mode: (0~255) angle change from A1(0°) to E(1080°), (128) is straight upward M2(540°) (2) Half Cycle Mode: (0~255) angle change from -105° to 105°, (128) is straight upward (0°)
CH2	Manual Speed setup: (0) Max Speed, (1~254) Speed increase, (255) Max Speed
CH3	Ignition ON/OFF: (0~253) Ignition OFF, (254~255) Ignition ON
CH4	Firing Duration setup: 0 and 255 is permanent fire (10s is limit duration time); 1~254 is 10~2540ms duration time (Manual firing duration = DMX Value * 10ms)
CH5	Program sequence setup: (0-2) no preset sequence; (3-255) preset sequence. DMX value = 2 + Sequence No.*2.55 (ROUND OFF) Detail information(CH5 DMX Reference Value) you can see the sequences list above.
CH6	Firing Pressure setup: (0~49) Pressure Relief Mode (Emergency Stop), (50~200) Pressure Armed Mode, (201~255) Pressure Relief Mode (Emergency Stop)

> Channel 1 (CH1): Angle Setup

Angle No.	Angle	DMX value
A1	0°	0
B1	15°	4
C1	30°	7
D1	45°	11
E1	60°	14
F1	75°	18
G1	90°	21
H1	105°	25
I1	120°	28
J1	135°	32
K1	150°	35
L1	165°	39
M1	180°	42
N1	195°	46
O1	210°	50
P1	225°	53
Q1	240°	57
R1	255°	60
S1	270°	64
T1	285°	67
U1	300°	71
V1	315°	74
W1	330°	78
X1	345°	81
A2	360°	85
B2	375°	89
C2	390°	92
D2	405°	96
E2	420°	99
...
A3	720°	170
...
E(END)	1080°	255

1. The first channel controls the firing angle. It defines to which angle the nozzle of CIRCLE FLAMER move to. The angle can be chosen anywhere between 0° to 1080° (DMX value 0 to 255).
2. The DMX value for angle of 0° is 3.5 (round up 4). the following formula can be used to calculate all other angles \angle in degree.

$$\text{DMX Value} = \angle * 0.2361$$

> Channel 1-Half Cycle Mode (CH1): Angle Setup

Angle No.	Angles	DMX Value
1	-105°	0
2	-90°	18
3	-75°	36
4	-60°	54
5	-45°	73
6	-30°	91
7	-15°	109
8	0°	128
9	15°	146
10	30°	165
11	45°	183
12	60°	201
13	75°	219
14	90°	237
15	105°	255

- The first channel controls the firing angle. It defines to which angle the nozzle of CIRCLE FLAMER move to. The angle can be chosen anywhere between -105° to +105° (DMX value 0 to 255).
- The DMX value for angle of 0° is 127.5 (round up 128). Use this value, following formula can be used to calculate all other angles ∠ in degree. Please always note the prefix of the angle.

$$\text{DMX Value} = 127.5 + (\angle * 1.2145)$$

> Channel 2 (CH2): Speed Setup

CH2: Speed Setup			
DMX value	0	1-254	255
Speed	Max Speed	Incremental of Speed	Max Speed

The second channel defines the rotate speed. It work together with Channel 1 for manual firing.

> Channel 3 (CH3): Ignition ON/OFF

CH3: Ignition		
DMX value	0-253	254-255
Ignition	CIRCLE FLAMER won't ignite	CIRCLE FLAMER ignites

The third channel activates the actual ignition. If the DMX value of this channel higher than 253, the CIRCLE FLAMER will ignite.

> Channel 4 (CH4): Firing Duration setup

Manual Firing Duration setup								
DMX value	0	1	2	3	4	254	255
Firing Duration	Permanent	0ms	10ms	20ms	30ms		2540ms	Permanent

The fourth channel is the firing duration setup.

Below formula can be used to calculate the firing duration (ms):

$$T = \text{DMX Value} * 10$$

> Channel 5 (CH5): Program Sequence setup

The fifth Channel allows to firing a preset sequence. Three DMX values can be used for one of the programmed firing sequence from above sequence list (refer to above sequence list table). Below formula can be used to calculate firing sequence:

$$\text{DMX Value} = 2 + \text{Sequence No.} * 2.55$$

Firing sequence mode/related firing channel							
DMX value	0~2	3~5	6~7	179~181	240~242
Sequence No.	N/A	1	2	70	94
Mode	Half Cycle Mode(180)					--	
	Full Cycle Mode(360)						

> Channel 6 (CH6): Mode setup

The sixth channel is the working mode of pump.

When the safety lock located at TEST MODE, set DMX value between 50-200 to test the system. For safety, the device will not pressuriser.

When the safety lock located at USER MODE, the device pressuriser activated by set DMX value between 50-200. The device can only make ignitions in Firing mode.

CH6: Mode setup			
DMX value	0-49	50-200	201-255
State	Pressure Relief	Pressure Armed	Pressure Relief

• Example 1: DMX console control

1. Set nozzle straight up

(CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 0, CH4 Firing duration = 0, CH5 Program sequence = 0, CH6 Compression mode = 50~200)

2. Set preset Sequence No. 31

(CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 0, CH4 Firing duration = 0, CH5 Program sequence DMX value = 80, CH6 Compression mode = 50~200)

3. Ignition

(CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 255, CH4 Firing duration = 0, CH5 Program sequence DMX value = 80, CH6 Compression mode = 50~200)

NOTE: After firing, The DMX value of CH3 must fall below 254, before an ignition can be made again. CH1 defines the nozzle position after firing.

• Example 2: Firing with DMX control (wave firing)

1. Set firing nozzle to the start point

(CH1 Angle = 0, CH2 Speed = 255, CH3 Ignition = 0, CH6 Compression mode = 50~200)

2. Set up firing speed

(CH1 Angle = 0, CH2 Speed = 50, CH3 Ignition = 0, CH6 Compression mode = 50~200)

3. Set firing end point and ignition

(CH1 Angle = 255, CH2 Speed = 50, CH3 Ignition = 255, CH6 Compression mode = 50~200)

4. Firing Nozzle will firing and make movement from start point to end point

NOTE: After firing, The DMX value of CH3 must fall below 254, before an ignition can be made again.

• Example 3: Firing with DMX control (fixed firing duration)

1. Set nozzle straight up

(CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 0, CH4 Firing duration = 0, CH6 Compression mode = 50~200)

2. Set firing duration 1s

(CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 0, CH4 Firing duration = 100, CH6 Compression mode = 50~200)

3. Firing 1s

(CH1 Angle = 128, CH2 Speed = 0, CH3 Ignition = 255, CH4 Firing duration = 100, CH6 Compression mode = 50~200)

NOTE: After firing, The DMX value of CH3 must fall below 254, before an ignition can be made again.

6. Operating with SHOWVEN host controller ZK6200/ZK6300

1) Hardware description

MODEL	ZK6200
Dimension	390×300×110mm
Weight	3.5kgWork
Input	110-240Vac, 50/60Hz
Work power	15w
Work Temp.	-10°C~ 50 °C
Interface	2*CAN port 2* media port (music trigger) 2*MIDI port (music trigger) 1* DMX512 input 1*DMX512 output.

Support Max. 200m communication cable

3350 mAh Li-battery (5h battery life when fully charged)

2) SHOWVEN host controller introduction

a) Standard DMX512 signal output.

b) Support 18units CIRCLE FLAMER (ZK6200) or 54units CIRCLE FLAMER (ZK6300) at the same time.

c) 5 standard dynamic modes: Synchronization, Center to Ends, Ends to Center, Left to Right, Right to Left. And an user defin able Special Effect mode, support 8 files, each file support 36000 lines maximum (effects lasts for 30min).

d) Multi trigger sources: manual, music or midi input.

e) RDMX monitoring function: system can send back circle flamer working status info such as pressure, warming etc. and display on the screen.

f) Emergency stop function.

3) Operational Panel



a) Cable Connection Area

AC Input: AC Power Input;

CAN: CAN communication input/output;

MIDI In: Midi time synchronous signal input;

DMX 512: DMX signal input/output;

LAN: network interface;

USB: program download interface, SparkularEdit200 software port.

b) Manual firing operation region



c) Mode Selection Area



There are 5 standard dynamic mode and 1 special effects mode. Each mode support 8 files, it can be switched easily on the mode selection area.

d) LCD display Area

F1: Main menu;

F2: File selection;

F3: Configuration;

F4: About host controller.

e) Edit/Control Area




Set circle flamer DMX address as below:

CIRCLE FLAMER No.	DMX Address
1	1
2	7
3	13
4	19
5	25
6	31
7	37
8	43
9	49
10	55
11	61
12	67
13	73
14	79
15	85
16	91
17	97
18	103


Note: wrong DMX address setup may leads to circle flamer out of control.

Setup of Host controller:

1. Press “F3” enter host controller configuration menu, DEVICE choose “CIRCLE FLAMER” as below.
2. Set Start No. and End No. of device.



Press "F1" back to main interface.



Press "PRE-HEAT", activate the compression of device.



1. Manual firing: Enter SEQUENCE No.99, press 1-18 to firing each unit, CIRCLE FLAMER can only firing at vertical upward.
2. Sequence firing: eg: firing at SEQUENCE 31, entering 31 at SEQUENCE, entering FIRING DURATION (Firing duration normally set at 0.5s, even the sequence firing duration is longer than 0.5s, the SEQUENCE will fully executed) , set the repeat counts, press "FIRING" to activate the device.

NOTE: Put safety lock at "TEST MODE" to check the signal connection and nozzle rotation status before use the device for firing.

For Emergency stop, press "PRE-HEAT", device will enter pressure relief mode, and stop emergently.

▲ Maintenance

1. To maintain the system in good performance and running status, it is recommended to running the device at least once per month.
2. Maintenance of the nozzle: Nozzle need to be cleaned up , and it is recommended that once every six months (depending on the environ ment and frequency of use). In the process of using the equipment, if the flame shape is seriously deformed or the fuel injection line is signifi cantly deformed or coarsened, the nozzle should be removed immedi ately for cleaning.
3. Maintenance of the O-ring: If it is found that the O-ring of the nozzle is damaged or ageing when cleaning the nozzle, the O-ring should be replaced in time (material and size of O-ring: fluororubber O-ring, the outermost diameter is 14 mm, and the line diameter is 2 mm).
4. In order to lubricate the pipeline and pump it is highly recommended to add 10-20ml castor oil per 10L canister.
5. Software can be upgraded with download cable from SHOWVEN.
6. Switchable power input design, switchable between 110V and 220V as show below (voltage will show on it). The power supply is located on the side of the electric control, and you should remove the cover in order to change it.



Warranty Instructions

- ▲Sincere thanks for your choosing Circle Flamer X-F3600, you will receive quality service from us.
- ▲The product warranty period is one year. If there are any quality problems within 7 days after shipping out from our factory, we can exchange a brand new same model machine for you.
- ▲We will offer free of charge maintenance service for machines which with hardware malfunction (except for the instrument damage caused by human factors)in warranty period. Please don't repair machine without factory permission.

★Below situations NOT included in warranty service:

1. Damage caused by improper transportation, usage, management, and maintenance, or damage caused by human factors;
2. Disassemble, modify or repair products without Showven's permission;
3. Damage caused by external reasons (lightning strike, power supply etc);
4. Damage caused by improper installation or use;

For product damage not included in warranty range, we can provide paid service.

★Invoice and warranty card are necessary when applying for maintenance service from SHOWVEN.

Warranty Card

Product Name:		Serial No.	
Purchase Date:			
Address:			
Problem Feedback:			
Actual Problem:			
Maintenance Detail:			
Service Engineer:		Service Date:	

SHOWVEN[®]



Showven Technologies Co., Ltd.

Add: Building B1, Changsha E Center No.18, Xiangtai Road, Liuyang Economic Development Zone, Changsha City, 410300, Hunan Province, P.R.China. Tel: +86-731-83833068

Web: www.showven.cn
E-mail: info@showven.cn