

BoomToneDJ.com

# *Quattro Moon*

## FRANÇAIS

---

### Instructions de Sécurité

- Conservez ce manuel pour une future consultation. Si vous revendez cet appareil, veuillez à transmettre également ce manuel d'utilisation au nouvel acquéreur.
- Déballez entièrement l'appareil ainsi que tous ses accessoires. Vérifiez qu'il n'y a aucun dommage et que l'appareil se trouve en parfait état.
- Il est important d'utiliser le câble d'alimentation secteur fourni.
- Toujours débrancher l'appareil avant une intervention technique ou avant son entretien.
- Température ambiante maximum pour un fonctionnement optimal de l'appareil : 40° C. Ne pas utiliser l'appareil si la température ambiante dépasse cette valeur.
- En cas de problème de fonctionnement, arrêtez immédiatement l'appareil. Ne pas essayer de le réparer soi-même. Contactez votre revendeur ou faites appel à un réparateur spécialisé et agréé. Il n'y a aucune pièce remplaçable par l'utilisateur.
- Ne pas brancher cet appareil sur un bloc de puissance variable type " Dimmer pack"
- Afin de réduire et d'éviter tout risque d'électrocution ou d'incendie, ne pas utiliser cet appareil dans un milieu humide ou sous la pluie.


### Caractéristiques :

- Alimentation électrique : 230Vac-50Hz
- Consommation électrique : 40W
- Pile de la télécommande : CR2025 type bouton
- Source lumineuse : 128 LED de 5mm ¼ Watt RGBWA
- Modes de fonctionnement : Auto, musical, avec télécommande
- Caractéristiques : Jeu de lumière Plug & Play facile à utiliser, faisceaux puissants
- Dimensions : 370x170x90mm
- Poids : 1,5 kg

## Télécommande :



- Lorsque vous pressez un bouton de la télécommande, assurez-vous de la diriger vers le jeu de lumière.
- La télécommande est livrée avec une pile. Lors de la première utilisation, veillez à retirer la languette en plastique transparent servant à éviter que la pile se décharge dans le carton.
- Si la distance de fonctionnement de la télécommande devient trop courte (moins de 3 mètres), il est alors temps de changer la pile.
- Pour se faire, ouvrez la trappe à l'arrière de la télécommande comme suit :



## Fonctions de la télécommande :

 : Allume/Eteint les LED

**FLASH** : Strobe

**Auto** : Mode automatique

**Speed+** : Vitesse plus élevée du programme auto

**Speed-** : Vitesse moins élevée du programme auto

**Sound** : Active le mode son

**Sens+** : Augmente la sensibilité du micro pour le mode son

**Sens-** : Diminue la sensibilité du micro pour le mode son

# ENGLISH

---

## Safety instructions :

- Please keep this User Manual for future consultation. If you sell the fixture to another user, be sure that he also receives this instruction booklet.
- Unpack and check carefully there is no transportation damage before using the fixture.
- Maximum ambient temperature is Ta : 40° C. Don't operate it where the temperature is higher than this.
- In the event of serious operating problem, stop using the fixture immediately. Never try to repair the fixture by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. There are no user serviceable parts inside the fixture.
- Do not connect the device to any dimmer pack.
- To prevent or reduce the risk of electrical shock or fire, do not expose the fixture to rain or moisture.
- Do not touch any wire during operation.


## Technical specifications:

- Power supply: 230Vac-50Hz
- Power consumption: 40W
- Battery remote control: CR2025 button cell 3 V
- Sound-control: via built-in microphone
- LED type: 128 X 5mm LED RGBWA
- Number of LEDs: 128
- Dimensions (LxWxH): 370x170x90mm
- Weight: 1.5 kg
- Maximum ambient temperature Ta: 45° C
- Maximum housing temperature TC: 50° C

## Remote:



- When actuating a button, always hold the remote control in the direction of the device (sensor inside).
- The remote control is supplied with a battery inserted. An insulating foil between the battery and the battery contacts prevents the battery from being discharged during storage. Prior to the first operation remove the foil from the battery support on the rear side of the remote control. Otherwise operation of the remote control is not possible.
- If the range of the remote control decreases (3 meters as a maximum), replace the battery. For this purpose, on the rear side of the remote control press the small bar with the groove to the right and at the same time remove the battery support. For operation, one 3 V button cell type CR 2025 is required. When inserting, pay attention that the positive pole of the button cell shows upwards in the support.



### CAUTION

Danger of explosion when battery is replaced improperly. Only replace by the same type. Please dispose of old and used batteries properly. Batteries are hazardous waste and should not be disposed of with regular domestic waste!

## Remote controller:

 : On / Off.

**Flash** : Strobe

**Auto**: Auto-Modes

**Speed+** : Auto speed fast

**Speed-** : Auto speed slow

**Sound** : Sound activate mode

**Sens+** : Sound sensitive max

**Sens-** : Sound sensitive min



BoomToneDJ.com

Importé par / Imported by **MSC** - 7, avenue du 1<sup>er</sup> mai - 91120 PALAISEAU - FRANCE

**Tel : +33 1 69 34 80 62** - [infos@msc-distribution.com](mailto:infos@msc-distribution.com)