

Setup Guide

Téléviseur
Televisor digital a color con pantalla de diodo orgánico
de emisión de luz (OLED)
Televizor

5-057-738-13(1)



EN	Setup Guide
FR	Manuel de configuration
ES	Guía de configuración
PT	Guia de Configuração

Sony Customer Support
U.S.A.:
<https://www.sony.com/tvsupport>
Canada:
<https://www.sony.ca/support>
U.S.A. 1.800.222.SONY (7669) Canada 1.877.899.SONY (7669)
Please Do Not Return the Product to the Store

Service à la clientèle Sony
Canada :
<https://www.sony.ca/support>
États-Unis :
<https://www.sony.com/tvsupport>
Canada États-Unis
1.877.899.SONY (7669) 1.800.222.SONY (7669)
Ne retournez pas le produit au magasin

Lea este manual antes de usar el producto
Centro de Asistencia de Sony
<https://esupport.sony.com/ES/LA/>
Llame al número telefónico que aparece en
su póliza de garantía.
Por favor no devuelva el producto a la tienda
donde adquirió el producto.

BRAVIA

K-55XR80 / 55XR80C
K-55XR8B / 55XR8C

1

★1 ★1★2

SB CN IM M5L16 CD

1.5 N·m/1,5 N·m
{15 kgf·cm}

2

3


4

1 2

M5L16

SB

→ x 2




1 2

M5L16

SB

→ x 2



1 2

M5L16

SB

→ x 2


5

★1 Only for limited region/country/model. / Uniquement pour certaines régions/pays/modèles. / Solo para regiones/países/modelos limitados. / Exclusivo para regiões/países/modelos especificados.


★2 Refer Reference Guide. / Reportez-vous au Manuel de référence. / Consulte la Guía de referencia. / Consulte o manual de instruções.




6




7






8




9




10




*3




*4



*5



*6



*7

