

Precautions for cFlamer Operation

1. After receiving the machine, before the first use, the oil drum needs to be filled with clean water. The machine should be pressurized and depressurized 30 times to clean the pipelines.
2. Whenever fueling the fuel tank or flush machine with water, please check the cleanliness of the fuel tank first, make sure there is no visible dust, sand, SPARKULAR consumables/remains, impurities etc in the fuel or water.
3. Fuel or water must be clear and transparent, replace fuel or water immediately whenever found it is turbid and dirty
4. If you find the fuel tank is not clean, please clean the machine pipe system. The operation is as below: clean the fuel tank with water, then fill 3L clean water in the fuel tank, execute pressurize and depressurize operation 30 times, with a interval of 15s, Empty the dirty water in fuel tank, fill clean water and repeat above pressurize and depressurize test until the water in fuel tank is clean.
5. To avoid impurities enter machine, we will send you higher precision fuel inlet filter in few days.