




When the device is shut down or started up, double-click the front button, and the four green lights on the side

设备开/关机









Thank you for using our products. In order to protect your legitimate rights and interests, remove your worries and improve the after-sales service to customers, our company has formulated this warranty regulation in accordance with the relevant provisions of the Consumer Rights and Interests

- 1. The products of the company are entitled to one year free warranty service
- 2. Please pack and deliver the products properly. We will not be responsible for
- any damage or loss in the process of delivery.

 3. During the free warranty period, the Company shall have the right to refuse service or charge materials and service fees at its discretion if any of the
- ② Disassembling the product without permission;
- 4 Accidental factors or man-made damage, such as water, broken, etc.
- 5. Please read the instructions carefully before using our products.
- 6. The warranty card must be stamped and dated by the seller, and properly kept to ensure your rights and interests.

PRODUCT SERIAL NUMBER	
PURCHASE DATE	
NAME	
ADDRESS	
TEL	
SIGNATURE/DEALER STAMP	

Please read the instructions carefully before using this product

varning: In order to reduce the risk of fire or electric shock, please do not put the equipment in the rain or

- wet place

 Note: please do not disassemble the equipment without permission. There is no part that can be repaired by the user. Please hand it over to qualified maintenance personnel Please use the attached charging line for charging. If you are unsure of the type of power available,
- please consult your dealer.

 The device has a built-in lithium battery. Please do not put it into the fire or near the heat source.
- This equipment is not waterproof, do not put into water or other liquids.
 Please do not attempt to repair the equipment, because open the lid after may make you touch the danger point voltage or other risks, if this equipment is the need for maintenance, please to qualified
- maintenance personnel for repair.
 5) If you are not using this product for a long time, you should unplug the charging cable.
- Avoid the power cord being trampled or the position of the socket and the connecting device being to tight at the plug.

1. 请在使用本产品前请详细阅读说明

整告・为了减少火灾或者触由的危险、请勿将本设备置于雨中或者潮湿的地方 注意: 请勿私自拆卸本设备,内部没有用户可维修的部件,请交给合格的维修人员处理)请使用附带的充电线进行充电,如果不确定可用的电源类型,请咨询您的经销商。 ①同读内附市的记录或记几还。 如果不确定 (可由的电源失至,谓台间总的至时间。 ②本设备没有防水功能,请勿投入火中或其他液体中。 ③本设备没有防水功能,请勿投入水中或其他液体中。 ④请勿尝试自行维修本设备,因为打开盖于后可能会使您能碰到危险电压点或其他风险,如果本设备需要进行维修,请交给合格的维修人员进行维修。 ⑤如果您长时间不使用本产品的时候,应该拨掉充电线。 ⑥避免电源线被踩踏或者在插头处插座和连接设备的位置绷的太紧。

specification

Channel	10 channel	System frequency response	20~20KHz
Distortion	< 0.05%	Reception sensitivity	< -110dbm @20dbsinad
Signal-to-noise ratio	>85dB	Transmission distance	30~50m
Latency	< 2 ms	Full working hours	5~6 hours(circumstantial)

Wireless System

- It is a mini wireless system, apply with 6.35mm audio devices, with strong anti-interference ability, through the obstacles of strong, stable transmission no pause etc in order to avoid signal attenuation, wrieless system should be close to acting area as far as possible to make, and with a large metal, wall, scaffolding and other objects at least keep a distance of 1.5 meters, and as far as possible to ensure that between transmitter and receiver are empty signal

Package contents




USB charging cable X 1





Device charging

Check battery capacity



Device on / off

Power on: Long press the button for 2 seconds when the transmitter and receiver are in power off state. The LED indicator light is always

Power off: Long press the button for 2 seconds while the transmitter and receiver are in power on state. The LED indicator light is off and the device shut down successfully.

After power on, the green light of the transmitter is always on, while the green light of the receiver is flashing, indicating that the device is not connected normally.


Device Testing

Connect the transmitter to the guitar and the receiver to the sound, long press the start button of transmitter and receiver, the green lights of the transmitter and receiver always keeps on, enter normal working condition. If the following situations occurs, please solve as follows.

Not paring successfully: If the transmitter green light keeps on and the eceiver red light flashing, proves that the paring is not successful. Should restart the transmitter and receiver. No sound after paring: If there is no green light on both


the transmitter and receiver, no sound when playing, you can try to re-pairing the products.

When using the device, there are signal interference around he device that cause the device not work properly. Frequency hopping can be performed on the device.



Reset code pairing


This product has been set by default before delivery and can be used directly after starting up. If the product can't be used directly, try to reset the code.



Pair code: When a transmitter connected with multiple receiver or transmitter and receiver are not the original equipment, can be long press on the code button to red light flashing, when transmitter and receiver normally on a green light , namely to code success!

More on other features

This system can support 10 sets to use at the same time without interference(above 500ft2). When using multiple equipment please turn on and test the wireless transceiver one to one to avoid signal crossing. After the test of each pair of wireless system is completed, then start and test the next pair of wireless system.



产品保修卡

尊敬的用户:

感谢您使用本公司的产品,为了保护您的合法权益,免除您的后顾之忧,

Device debugging

performances at the same time!

A transmitter can be used with multiple receivers. $\begin{tabular}{ll} \hline For example : There are four effects on a stage, you can use one transmitter and four receivers Connect and the stage of th$

Device debugging:
After turn off all the similar wireless system, use thin iron wire to long press the code button and release the button
until the red light flashing on four receivers. Use thin iron wire to long press the code button of one transmitter,
release the button when the red light flashing on the transmitter and all the receivers. It will take 20 seconds.
When the green light of transmitter and receivers is always on, four receivers can receive signal from one
transmitter at the same time. One-to-many functions can be realized. All code debugging time should be
completed within 20 seconds.

